



Engineering | Fabrication | Manufacturing High Performance Automotive  
Hardware and Software

502.895.3660 · 502.290.6245 fax

## C2-Step User Programming Instructions

Use the following procedures to program the C2-Step RPM into your factory ECU. NOT all software has C2-Step enabled. Please contact C2Motorsport if you would like to purchase/install this option.

### Initializing 2-Step Function:

1. Turn on ignition
2. Turn **OFF** ESP/ASR (OEM traction control)
3. Start engine while in neutral
4. Clutch and brake should then be released
5. Car must be not moving during the procedure (Engage E-Brake)
6. Depress and release the BRAKE fully two times; Depress and release the CLUTCH three times

**\*\*\* Execution of Step 6 must not exceed 5 seconds\*\*\***

When preformed correctly, the MIL/CEL will start blinking. Driver can now set the target rpm into memory

### Setting the 2-Step RPM:

1. Increase the RPM to the desired launch by using the gas pedal
2. Press the brake once and the launch rpm is stored as launch rpm
3. MIL will stop blinking

### FAQ's

Factory traction control must be TURNED OFF in order for 2-Step to function  
Must depress clutch to utilize 2-Step \*\*sitting at idle without clutch depressed will allow RPMs to go past set point\*\*

2-Step can be set as many and as often as user chooses.

Minimum launch: 1500 rpm

If battery is disconnected, you are required to repeat setup procedure

C2Motorsports is not responsible for any use/misuse of this option